



TG268, TG298 Firmware Upgrade Instructions

Copyright

© 2025, FLIR Systems, Inc.

All rights reserved worldwide. Names and marks appearing herein are either registered trademarks or trademarks of FLIR Systems and/or its subsidiaries. All other trademarks, trade names or company names referenced herein are used for identification only and are the property of their respective owners.

Document identity

Publ. No.: NAS100280
Release: AC
Commit: 105983
Head: 105983
Language: en-US
Modified: 2025-07-02
Formatted: 2025-07-02

Website

<http://www.flir.com>

Customer support

<http://support.flir.com>

Disclaimer

Specifications subject to change without further notice. Models and accessories subject to regional market considerations. License procedures may apply. Products described herein may be subject to US Export Regulations. Please refer to exportquestions@flir.com with any questions.

1 Upgrading the Firmware

1.1 GENERAL

This document explains how to upgrade the TG268/TG298 firmware to version 1.1.2. If you are not confident that you can complete the upgrade, please contact our customer support site:

<https://support.flir.com>

1.2 Firmware Upgrade Details

Version 1.1.2 firmware offers the following improvements and enhancements:

- Optimized the Trend View function.
- Added video Pause/Resume, Fast-Forward, and Rewind functions. Download the latest user manual for complete instructions on these new features.

1.3 Prerequisites

To upgrade the firmware, you will need:

- TG268/TG298 meter.
- PC and USB cable.
- Firmware upgrade file obtained from the support site, as explained below.

1.4 Obtaining the Firmware Upgrade File

1. Go to the support site: <https://support.flir.com>
2. Click on the **DOWNLOADS** menu heading, as shown.




Figure 1.1 Click 'DOWNLOADS'.

3. Click **Software and Firmware** as shown.

Software and Firmware [login needed]

Figure 1.2 Click the 'Software and Firmware' item from the options list.

4. Type your **Email Address** to log in or to create an account, as shown. Click **Continue**.

Sign in

Or create a new account by entering your email address below

EMAIL ADDRESS

EMAIL ADDRESS


CONTINUE

TG268, TG298 Firmware Upgrade Instructions

© 2025, FLIR Systems, Inc.

#NAS100280; r. AC/105983/105983; en-US

5. For Figure 1.3, below, 1. Type **TG268** or **TG298** in the search field; 2. Select **FLIR / Extech Meters Software** from the pull-down menu; 3. Select **FLIR Software** from the pull-down menu; 4. Click **SEARCH**; 5. Click the upgrade file to download it to your PC.



The screenshot shows a web interface titled "Software and Firmware". It includes a link "Click here for the 10 most recently uploaded downloads". Below this is a "Product" section with two dropdown menus. The first dropdown is set to "FLIR / EXTECH Meters Software" (callout 2) and the second is set to "FLIR Software" (callout 3). To the right of these is a text input field containing "TG298" (callout 1) and a blue "SEARCH" button (callout 4). Below the search fields is a message: "Please click one of the links below to get more info about the download. Software for FLIR Test & Measurement meters can be found here: [available firmware update files would be listed here]" (callout 5).

Figure 1.3 Follow the steps to complete the download process.

1.5 Firmware Upgrade Procedure

NOTE

The meter battery must be charged to at least 50% before continuing.

1. Power the meter and connect it to the PC using the supplied USB cable.
2. The PC should now recognize the meter as an external storage drive.
3. Move the firmware file from your PC to the root (top level) directory of the meter.



CAUTION

Drag only the upgrade file into the meter's root directory. Do not drag other files or folders that may accompany the upgrade file (*readme.txt*, for example).

4. Safely eject the meter from the Windows PC by right-clicking the drive letter (representing the meter) in File Explorer and selecting **Eject**.
5. Physically disconnect the meter from the PC and disconnect the USB cable from the meter.
6. Follow the prompts on the meter display to complete the upgrade.



CAUTION

Do **NOT** switch OFF the meter while it is upgrading. If the meter is switched off during the upgrade process, it may not be recoverable and would have to be returned to FLIR for service.

7. If you require assistance, please visit the customer support site.
<https://support.flir.com>

